

Perfect fit blinds

Measuring instructions



Firstly, all you need to do is measure the glass size of your uPVC window and enter your width and drop for your price. Your blind will come ready made to clip straight in. You will need 6mm clearance from the edge of your frame to any handles



Secondly, you need to measure the beading depth of your uPVC window and choose your required bracket from our drop down menu, either 'up to' 18mm, 20mm or 24mm. You can use a 'depth gauge' as shown or simply place a ruler across the corner and measure down to the glass.

